

Install the Chassis on a Rack

Use this procedure to mount the chassis on the rack.

Procedure

1. Attach the left and right mounting brackets to the chassis using the M4 Phillips flat-head mounting screws for mounting brackets and tighten them to torque value of 1.5 N-m (13.3 lbs-in).

Callout	Component
1	M4 Phillips flat-head mounting screws for mounting brackets (48-2029-01)
2	Right Bracket (700-116388-01) and Left Bracket (700-116386-01)
3	ACT LED

2. Install the four post slider or two post slider on the rack.
3. Insert the chassis (with brackets) onto the sliders assembled on the rack.
4. After completely inserting the chassis, fasten it with four 12-24 Pan head mounting screws on each side of the bracket.
5. Using a number-2 Phillips screwdriver, tighten the screws to a torque value of 4.65 N-m (41 lbs-in).